



GL-23001

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23002

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23003

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23004

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23004

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23005-A

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23005-B

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GLOIRIO[®]
style your interior

ARTIQUE
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

GL-23006-A

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23006-B

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23007

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23008

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23009

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS **6MM**



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23010

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23011

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23012

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL



GL-23013

WATCH OUT FOR GLOIRIO MARK ON EACH SAMPLE TO AVOID DUPLICATION

GLOIRIO[®]
style your interior

 **ARTIQUE**
PANELS

FEATURES



TERMITE &
BORER
RESISTANT


PS

HIGH
GRADE
PS



QUICK
INSTALLATION

THICKNESS 6MM



**USE DIAMOND BLADE TO CUT
PANELS FOR BETTER RESULTS.**

• TO AVOID BATCH VARIATIONS USE SAME BATCH MATERIAL